


Getting started with IoT WiFi Button

Connect to button

- **Press** button more than **20** seconds and **release**.
- Button **RED** indicator starts **flashing** and WiFi **Access Point** (AP) with name like “**BUTTONCF3E7B1640E0**” will be available.



- Connect to **Button** using default password “**password**” (change it in the web interface later)

Open Web interface

- Go to URL <http://192.168.4.1>
- Use default user password “**admin**” (change it in web-interface later). **NB!** Remember new password or write it down, it can't be recovered without vendor service.


Default password: admin

Password:

Submit


«USER» settings

- Change user password for web interface.
- **NB!** Remember it or write it down, it can't be recovered without vendor service.




“WiFi” settings

- Choose SSID from list or enter manually
- Enter password for selected SSID



“WiFi AP” settings

- Change user password for Access Point



“URL” settings

- Check “Open URL” if you want to use this feature
- “Single click URL” will be opened on single click
- “Doubleclick URL” will be opened if button pressed twice in 2 seconds
- “Longpress URL” will be opened if button pressed more than 5 seconds and less than 20 seconds
- “Battery URL” sends battery status to specified URL on every click
- “GET parameter name” – parameter name which contains battery level value. Used in “Battery URL”

URL settings

Open URL

Single click URL
http://127.0.0.1/singleclick

Doubleclick URL (less than 2 sec between clicks)
http://127.0.0.1/doubleclick

Longpress URL (more than 5 sec)
http://127.0.0.1/longpress

Battery URL
http://127.0.0.1/battery

GET parameter name
batt

Submit

“Telegram” settings

- Check “Send to Telegram” if you want to use this feature
- “Bot token” – paste token from Telegram BotFather
- “Single click”, “Long click”, “Double click” – messages for appropriate events
- “Clear all subscribers” – remove all subscribers

Telegram settings

Send to Telegram

Bot token:
Bot token

Singleclick message :
Single click

Longclick message :
Long click


Doubleclick message :
Double click

Submit

Clear all subscribers

“MQTT” settings


- Check “Use MQTT” if you want to use this feature
- “Host address” – address of MQTT server
- “Port” – Port used by MQTT server
- “Client ID” – client id for this MQTT device
- “Login” and “Password” – user credentials
- “Topic” – topic for message publishing



The screenshot shows a web browser window titled "MQTT settings" with the address bar displaying "192.168.4.1/mqtt". The interface features a navigation bar with buttons for "User", "WiFi", "WiFi AP", "URL", "Telegram", "MQTT", and "Battery". Below this, the "MQTT settings" section includes a checkbox for "Use MQTT", which is currently unchecked. The form contains several input fields: "Host address" (placeholder: domain or IP address), "Port" (placeholder: port number), "Client ID" (value: button0808421640e0), "Login" (value: login), "Password" (value: password), and "Topic" (value: login). A "Submit" button is located at the bottom of the form.

Restart

- Restart button after configuration is finished!!!



The screenshot shows a web browser window titled "WiFi settings" with the address bar displaying "192.168.4.1/wifi". The interface features a navigation bar with buttons for "User", "WiFi", "WiFi AP", "URL", "Telegram", "MQTT", and "Battery". Below this, the "WiFi settings" section includes a "Current IP: 0.0.0.0" indicator, a "SSID:" label, a "Choose" dropdown menu set to "Manual", an "or" separator, an "Enter SSID" input field, a "Password:" label, and a "password" input field. A "Submit" button is located below the password field. At the bottom of the form, a green "Restart button" is highlighted with a red circle.