


USB connection  
for On-line mode  
Or  
5V VBUS power for  
Off-line Mode



- **Test Box support both On-line(with PC)/ Off-line mode(Without PC). If Off-line mode is desired, use USB adapter that is included in the package.**
- **Press one button to program. This button is used to enter boot loader mode to update Firmware.(Pressing the button then plug-in USB will enter boot loader mode)**
- **Test port is optional if Connection Test is desired. Test JIG senses Test port connection and perform Connection test if both ends are connected.**