Type 485 Soil Comprehensive Sensor

User's Guide

Chapter 1 Product Introduction

1.1 Product overview

The soil integrated sensor is suitable for measuring soil temperature, moisture, total soil salt (conductivity), soil pH and nitrogen, phosphorus and potassium. The soil comprehensive sensor creatively measures the seven parameters of conductivity, moisture, temperature, ph, and nitrogen, phosphorus and potassium, which greatly facilitates the customer's systematic assessment of soil conditions.

Compared with the German original high-precision sensor and the actual soil drying weighing method calibration, the sensor has high accuracy, fast response and stable output: it is less affected by the salt content of the soil and is suitable for various soil qualities. Can be buried in the soil for a long time, resistant to long-term electrolysis, corrosion resistance, vacuum potting, and completely waterproof.

1.2 Scope of application

It is widely used in scientific experiments, water-saving irrigation, greenhouses, flowers and vegetables, grassland pastures, rapid soil testing, plant cultivation, sewage treatment, grain storage, and the measurement of various particulate water content and temperature.

1.3 Measurement parameters and hardware parameters

parameter	content
Power supply	12-24V DC
output signal	RS485
Temperature	−40 °C −80 °C
measurement range	
Temperature accuracy	±0.5°C
Temperature resolution	0.1℃
Moisture	0-100%
measurement range	
Moisture accuracy	$\pm3\%$ in the range of 0-53%; $\pm5\%$ in the range of 53-100%
Moisture resolution	0.10%
Conductivity measurement range	0-10000us/cm
Conductivity resolution	10us/cm
pH measurement range	3-9рН
pH measurement accuracy	±0.3pH
pH resolution	0.01pH
NPK measurement	0-1999mg/kg

range								
VPK measurement $\pm 2\%$ F.s								
accuracy								
NPK resolution	1mg/kg (mg/1)							
Storage	−20°C−60°C							
environment								
Working pressure	0.9-1.1atm							
range								
Response time	<1s							
Protection level	IP68							
Installation method	Embed all or insert all probes into the measured medium							

Note: The details of all measurable parameters of this series of products, please refer to the actual product purchased.

When measuring frozen icy soil layers, the moisture value will be low and inaccurate, requiring user compensation.

The factory default product is suitable for measuring ordinary yellow soil, black soil and red soil. It is not suitable for absolute moisture measurement on saline-alkali soils, sandy soils, or other powdery objects with high salinity. It can still characterize the relative moisture difference. For this type of moisture measurement, you should contact the manufacturer for separate calibration.

1.4 Calculation method and meaning of soil moisture

The soil moisture calculated by this sensor is soil

volumetric moisture content (also called soil volumetric moisture content), which is what people call "soil moisture" and "soil moisture" in a popular sense.

The calculation method of soil volumetric water content is the ratio of the volume of water in the soil to the total volume of the soil. 0% means completely dry soil without any moisture, and 100% means completely water without any soil.

1.5 System framework diagram

This sensor can be connected and used alone. First, use 12V DC power supply. The device can be directly connected to a PLC with a 485 interface, and it can be connected to a singlechip microcomputer through a 485 interface chip. The singlechip microcomputer and PLC can be programmed through the specified modbus protocol to cooperate with the sensor. At the same time, use USB to 485 to connect to the computer, and use the sensor configuration tool provided by our company for configuration and testing.



This product can also be used in combination of multiple sensors on a 485 bus. In theory, one bus can connect more than 16 485 sensors. If you need to connect more 485 sensors, you can use 485 repeaters to expand more 485 devices. One end is connected to the PLC with 485 interface, and the single-chip microcomputer is connected through the 485 interface chip, or it can be connected to the computer by using USB to 485. Use the sensor configuration tool provided by our company for configuration and testing.



Chapter 2 How to Use

2.1Inspection before equipment installation

Please check the equipment list before installing the equipment:

name	Quantity
High precision	1set
sensor	
12V waterproof	1 set
power supply	(Optional)
USB to 485	1 set
device	(Optional)
Warranty	1 serving
card/certificate	

2.2Interface description

The power interface is a wide-voltage power supply that can output 12-24V. When wiring the 485 signal line, pay attention to the A/B two lines can not be reversed, and the address of multiple set devices on the bus can not conflict. The line sequence description is shown in the following figure (table):



	Thread color	Description
pow	brown	Power is positive (12-
er		24VDC)
supp ly	black	Power negative
Com	Yellow	485-A
mun	(gray)	
icati	color	
on	blue	485-В

Note: Please be careful not to connect the wrong wiring sequence, the wrong wiring will cause the equipment to burn.

The factory default provides 1.25 meters of wire, customers can extend the wire as needed or wire in order.

Note that there is no yellow line in the line sequence that may be provided in some factory batches. At this time, the gray line is equivalent to replace the yellow line.

2.3Product appearance

The picture below is the appearance of our product:



2.4Quick test method

Select a suitable measurement location, avoid rocks, ensure that the steel needle does not touch hard objects, throw away the surface soil according to the required measurement depth, maintain the original tightness of the soil below, hold the sensor vertically and insert it into the soil. Do not shake left and right. It is recommended to measure multiple times for average value within a small range of a measuring point.

2.5Buried measurement method

Dig a pit with a diameter> 20cm vertically, insert the sensor needle horizontally into the pit wall at a predetermined depth, and fill the pit tightly. After a period of stability, measurement and recording can be carried out for several days, months or even longer.

2.6Notes

1. All steel needles must be inserted into the soil during measurement.

2. Avoid strong sunlight directly shining on the sensor to cause excessive temperature. Pay attention to lightning protection in the field.

3. Do not bend the steel needle violently, pull the lead wire of the sensor forcefully, and do not hit or hit the sensor violently.

4. The sensor protection grade is IP68, and the sensor can be soaked in water.

5. Due to the presence of radio frequency electromagnetic radiation in the air, it is not suitable to stay in the air for a long time with electricity.

Chapter 3 Configuration Software

Installation and Use

Our company provides supporting "sensor monitoring software", which can easily use the computer to read the parameter of the sensor and modify the device ID and address of the sensor flexibly.

3.1Connect the sensor to the computer

After connecting the sensor to the computer through USB to 485 and providing power supply, you can see the correct COM port in the computer (check the COM port in "My Computer-Properties-Device Manager-Port").



As shown in the figure above, your serial port number is COM10 at this time, please remember this serial port, you need to fill in this serial port number in the sensor monitoring software.

If the COM port is not found in the device manager, it means that you have not inserted the USB to 485 or the driver has not been installed correctly, please contact a technician for help.

3.2 Use of sensor monitoring software

The configuration interface is as shown in the figure. First, obtain the serial port number and select the correct serial port according to the method in chapter 3.1, and then click to automatically obtain the current baud rate and address to automatically detect all devices and baud rates on the current 485 bus. Please note that you need to ensure that there is only one sensor on the 485 bus when using the software to automatically obtain it.

ensor Management V3.	6		•
Sensor Ma	anagement	Software	= 6
0 ppm	Soil Moisture	Atmosphere Ombar	System Configure Com Port 0000 ~ Baud 9600 ~ Connect
0 %	0 %	0	Addr 1
Temperature O°C Gas Concentration	Illuminance O Lux	Analog2 Found the device, NO: 1Baud rate:4800	Communication Settings Set Baud 9600 V Set Set Addr 1 ÷ Set
Орј	pm	OK	ter Configure perl: Lower1: R W
Time			Upper2: Lower2: R V Deviation1: Deviation2: R V
 Normal Analog Illuminance 	○ Gas ○ Atmosphere ○ The 02	○ CH20	Drop1: Drop2: R W

Then click to connect the device to get the sensor data information in real time.

If your device is a gas concentration sensor, please select "gas concentration sensor" in the sensor type, "formaldehyde transmitter" for formaldehyde sensor, "analog transmitter module" for analog transmitter, and "atmospheric pressure" for atmospheric pressure sensor Sensor", illuminance sensor selects "Illuminance 20W", oxygen sensor selects "Oxygen transmitter", and other sensors select the default "No other sensor".

3.3Modify the baud rate and device ID

When the device is disconnected, click the device baud rate and set address in the communication settings to complete the related settings. Please note that after setting, please restart the device, and then "automatically obtain the current baud rate and address" to find the address And the baud rate has been changed to the address and baud rate you need.

CHAPTER 2 Basic Communication

2.1 Basic communication parameter

parameter	content
coding	8-bit binary
data bit	8-bit
parity check i	ait no
stop bid	1-bit
erron checkin:	g CRC(redundant cyclic code)
baud rate	2400bps/4800bps/9600bps
	Can be set, the factory default is 9600bps

2.2 Data frame format definition

Using Modbus-RTU communication protocol, the format is as follows:

Initial structure \geq 4-byte time Address code = 1 byte Function code = 1 byte Data area = N bytes Error check = 16-bit CRC code End structure \geq 4-byte time Address code: the address of the

Address code: the address of the sensor, which is unique in the communication network (factory default 0x01).

Function code: the command function instruction issued by

the host, this transmitter only uses function code 0x03 (read register data).

Data area: The data area is the specific communication data, pay attention to the high byte of 16bits data in front.

CRC code: two-byte check code.

Interrogation frame

Address	Function	Register	Registe	r Check	code	Ch	eck code
code	code	start address	length	low	bit	h	igh bit
1byte	1bytes	2 bytes	2 bytes	s 1 b	yte		1 byte
Re	ply frame						
Addres	Function	Quantity of	Data 1	Data 2	Data	N	Check
s code	code	valid byte	area	area	area	a	code
1 byte	1 byte	1 byte	2 bytes	2 bytes	2 byt	es	2 bytes

2.3 Register address

regisiter address	PLC or configuration address	content	operating
0006H	40007 (40007)	pH value (unit 0.01pH)	read only
0012H	40013 (40019)	soil humidity (unit: 0.1%RH)	read only
0013H	40014 (40020)	soil temperature (unit: 0.1℃)	read only
0015H	40016 (40022)	soil conductivity (unit: 1us/cm)	read only
001EH	4001F (40031)	soil nitrogen (unit mg/kg)	read only
001FH	40020 (40032)	soil phosphorus (unit mg/kg)	read only

0020	0H 400	21 (4003	3)	soil (un	potassium it mg/kg)	read only
0100	H 401	01 (4025	7)	device address (0- 255)		read only
0101	Н 401	02 (4025	8)	ba (2400/	nud rate (4800/9600) ¹	read and write
2.4 Co ex	ommunic planatio	cation n	pı	otoco	l examj	ple and
2.4.1 F t Inte	Read the he device errogation	soil temj e address frame	pera 0x	ature a 01	nd humidit	y value of
Address code	Function code	Initial address		Data length	Check code low bit	Check code high bit
0x01	0x03	0x00 0x12		0x00 0x02	0x64	0x0E
Res	ponse frar	ne (for exa	amp	le, the t	temperature i	s -10.1 °C and
the hum	idity is 65.	8%RH)				

Address code	Function code	Effective words	Humidity value	Tempe rature value	Check code low bit	Check code high bit
0x01	0x03	0x04	0x02 0x92	0xFF 0x9B	0x5A	0x3D

Soil temperature:

Upload in the form of complement when the temperature is below zero

FF9BH(hexadecimal)=-101=>temperature=-10.1 °C

Soil moisture:

292H (hexadecimal) = 658 => humidity = 65.8%RH

2.4.2 Read the soil moisture value of the device address 0x01

Interrogation frame

Address	Function	Initial	Data	Check code	Check code
code	code	address	length	low bit	high bit
0x01	0x03	0x00 0x12	0x00 0x01	0X24	0x0F

Response frame (for example, the humidity is 7.4%RH)

Address	Function	Quantity	Humidity	Check code	Check code
code	code	of byte	value	low bit	high bit
0x01	0x03	0x02	0x00 0x4A	0x39	0xB3

Soil moisture:

4AH (hexadecimal)=74=>humidity=7.4%RH

2.4.3 Read the soil conductivity of the device address 0x01

Interrogation frame

Address	Function	Initial	Data	Check code	Check code
code	code	address	length	low bit	high bit
0x01	0x03	0x00 0x15	0x00 0x01	0X95	0xCE

Response frame (for example, read conductivity of 1500us/cm)

Address code	Function code	Quantity of byte	Conductivity	Check code low bit	Check code high bit
0x01	0x03	0x02	0x05 0xDC	0xBA	0x8D

Soil conductivity:

5DCH (hexadecimal) = 1500 => conductivity = 1500us/cm

2.4.4 Read the soil pH of the device address 0x01

Interrogation frame

Address Function		Initial	Data langth	Check code	Check code
code	code	address	Data length	low bit	high bit
0×01	0x03	0x00	0x00	0864	0v0B
0X01	0X03	0x06	0x01	0A04	0X0D

Response frame (for example, read the pH is 3.08pH)

Address code	Function code	Quantity of byte	Conductivity	Check code low bit	Check code high bit
0x01	0x03	0x02	0x01 0x34	0xB8	0x03

Instructions for pH calculation:

0047H (hexadecimal)=308=>pH=3.08pH

2.4.5 Read the value of soil nitrogen, phosphorus and potassium at device address 0x01

Interrogation	frame
---------------	-------

Address	Functio	Initial	Data	Check code	Check code
code	n code	address	length	low bit	high bit
0×01	0×02	0x00	0x00	0x65	0vCD
0X01	0X03	0x1E	0x03	0X05	UXCD

Response frame

Addr ess code	Func tion code	Effe ctive word s	Nitroge n content	Phosph orus content	Potassi um content	Check code low bit	Check code high bit
0x01	0x03	0x06	0x00 0x20	0x00 0x25	0x00 0x30	0xB1	0x6D

Nitrogen, Phosphorus, Potassium content:

0020 H (hexadecimal)=32=>nitrogen=32mg/kg

0025 H (hexadecimal)=37=>phosphorus=37mg/kg

0030 H (hexadecimal)=48=>potassium=48mg/kg

2.4.6 Read the value of soil nitrogen at device address 0x01

bit

0x9C

bit

0xB9

Interrogat	ion frame					
Address	Function	Initial	Data	Check code	Check code	
code	code	address	length	low bit	high bit	
0x01	0x03	0x00 0x1e	0x00 0x01	0xE4	0x0C	
Response frame						
Address code	Func tion	Effective words	Nitrogen	Check code low	Check code high	

Nitrogen content:

0x01

0020 H (hexadecimal)=32=>nitrogen=32mg/kg

0x02

2.4.7 Read the value of soil phosphorus at device address 0x01

 0×00

0x20

Interrogation frame

IoTHubTech@gmail.com 18

code

0x03

Address	Function	Initial	Data	Check code	Check code
code	code	address	length	low bit	high bit
0x01	0x03	0x00 0x1f	0x00 0x01	0xB5	0xCC

Response frame

Addre	Function	Effecti	Phosph	Check	Check
SS	Function	ve	orus	code low	code high
code	code	words	content	bit	bit
0x01	0x03	0x02	0x00	0x79	0x9F
			0x25		

Phosphorus content: 0025 H (hexadecimal) = 37 => phosphorus

= 37 mg/kg

2.4.8 Read the value of soil potassium at device address 0x01

Interrogation frame

Address	Functio	Initial	Data	Check code	Check code
code	n code	address	length	low bit	high bit
0x01	0x03	0x00 0x20	0x00 0x01	0x85	0xC0
Response	frame				
Addre	Functi	Effective	Potassi	Check	Check
SS	on	words	um	code low	code high
code	code	words	content	bit	bit
0x01	0x03	0×02	0x00	0xB8	0x 50
0401	0403	0X02	0x30	UADO	0720

Potassium content: 0030 H (hexadecimal) = 48 => phosphorus = 48mg/kg